

AIRGIZMOS, LP

Installation Instructions for AirGizmos Gust Locks

Revision 2, March 2018



Thank you for purchasing an AirGizmos Gust Lock.

Please follow the steps below to secure it properly in place.

Step 1: Position the Gust Lock



Make sure that both parts of the wing are aligned flat and slide on the Gust Lock to cover the split between two surfaces.


The Gust lock shown here is rotated with the long surface to be perpendicular to the latch which is the desired position for fabric surfaces” You can rotate the latch mechanism to the position that works best for your application.

Step 2: Tighten the Strap



Holding Gust Lock firmly in place, tighten the strap.

Step 3: Hold the Strap and Tab



After the strap has been tightened, lift it up and hold **together** with the tab.

It is important to keep tension on the strap.

Step 4: Lock the Gust Lock



Firmly holding the strap and the tab, lower them in the direction of the strap to lock the Gust Lock.